

# LOAD LEVEL INDICATOR SPEC SHEET

#	PART#	DESCRIPTION
REPLACEMENT PARTS		
1	1000-0101	5/6" LOCK NUT
2	1000-0109	5/16" FLAT WASHER
3	1091-0007	1 1/8" JAM NUT
4	1091-0008	INDICATOR ARROW
5	1091-0006	VITON GASKET FOR LOAD LEVEL
6	1091-0003	6" FOAM FILLED PLASTIC FLOAT BALL
	1076-0002	6" STAINLESS STEEL FLOAT BALL
7	1091-0029	FLOAT PIVOT WELDMENT
8	1091-0028	FLOAT ARM WELDMENT
9	1091-0030	VITON O-RINGS (REQUIRES 2)
10	1091-0015	3/8"-16 UNC BUTTON CAP SCREW
11	1000-0118	3/8 LOCKWASHER

